



Step 1: loosen screw nut A and B, let A and B height to horizontal pipe about 5mm upper than before. Then put bathtub to the wall, if it can fit well. Then tighten screw nut A and B.

Step 2: if adjust screw A and B still not fit wall well, then loosen screw C and D, let C and D height to horizontal pipe about 5mm lower than before. Then put bathtub to the wall. If no gap then tighten screw nut.

Remarks: if adjust step 1 can solve problem, no need continue step 2.

