




ISTRUZIONI DI MONTAGGIO


INSTALLATION INSTRUCTIONS

A




MIN 35mm - MAX 55 mm



B




C




-1" Uscita doccia ---- Shower exit

1 bar	8,9	l/min
2 bar	13,2	l/min
3 bar	16,5	l/min
4 bar	21	l/min
5 bar	27	l/min




-2" Uscita doccia ---- Shower exit

1 bar	8,9	l/min
2 bar	13,2	l/min
3 bar	16,5	l/min
4 bar	21	l/min
5 bar	27	l/min



-3" Uscita Vasca ---- Bath exit

1 bar	15,2	l/min
2 bar	23	l/min
3 bar	30	l/min
4 bar	39	l/min
5 bar	44	l/min



PRESSIONE MINIMA DI SERVIZIO :.....0,5 bar
 PRESSIONE DI SERVIZIO MASSIMA :.....5 bar
 PRESSIONE D'USO CONSIGLIATA :.....3 bar
 TEMPERATURA ACQUA CALDA MAX :.....80°C
 TEMPERATURA ACQUA CALDA CONSIGLIATA :.....60°C

In caso di pressione d'esercizio superiore a 5 bar è consigliabile installare un riduttore di pressione sulle tubature di alimentazione.

MINIMUM WORKING PRESSURE:.....0,5 bar
 MAX OPERATING PRESSURE :.....5 bar
 RECOMMENDED OPERATION PRESSURE :.....3 bar
 MAX HOT WATER TEMPERATURE :.....80°C
 RECOMMENDED HOT WATER TEMPERATURE :.....60°C

In case of operating pressures higher than 5 bar it is recommended to install a pressure reducer on the feeding tubes.

Istruzioni montaggio
 Per Art- 38556/3
 Per corpo incasso Art - 09494

External parts instruction
 For item - 38556/3
 For built-in body item - 09494

bongio

Mario Bongio s.r.l.

Via Aldo Moro, 2

28017 San Maurizio d'Opaglio (NO) - Italy

tel: +39 0322 967248 fax: +39 0322 950012

www.bongio.com - info@bongio.it

© Copyright of Bongio s.r.l.